

# PRO BAG 3 / PRO BAG 4




PRO Bag 3

PRO Bag 4



## DELSEY



### Hide-a-way handles

Clever design produces a style so streamlined you'll need to look twice to see just how these handles stow away.



### Front Organizer

A home for every business essential in the maxi-room, multi-pocketed front organizer section.

### PRO Bag 3

Customizable interior with room for:

2 Pro SLR's with attached lenses, 4 to 5 additional lenses, Pro Flash, Light Meter, many more accessories & zippered top mesh pocket.

### PRO Bag 4


Customizable interior with room for:

Pro SLR with attached lens, additional lenses, Pro Flash, Light Meter, many more accessories & zippered top mesh pocket.

### Features:

- Front Organizer Section
- Two Side Pockets
- Detachable Film Pouch\*
- Hide-a-way handles
- Tripod carry system
- Padded shoulder strap
- Padlock
- Airline carry-on

\* PRO Bag 3 only



Dimensions (cm)		PRO Bag 3	PRO Bag 4
Internal	Length	30	28
	Height	19	17
	Depth	22	20
External	Length	42	32,5
	Height	20	20
	Depth	28	25,5
<b>Weight (gr)</b>		2,030	1,350
<b>Colour</b>		Order Code	Order Code
Black		DELPROBAG3	DELPROBAG4

Airline carry-on size regulations do change. Please check with your carrier before departure.